

ModuLT Air Disc Brake

Preventative Maintenance Recommendations

Preventative maintenance is important for many vehicle systems including all types of foundation brakes and air disc brakes are no exception. The following preventative maintenance program is recommended for the Haldex ModuLT Air Disc Brake in addition to industry recommended practices for brake system maintenance. The table below specifies maximum service intervals. Depending on the vehicle application and/or type of driving, there may be a need for more frequent inspections. Be sure to review the vehicle manufacturer's maintenance recommendations as well.



- C** = Check
- I** = Inspection
- *** = With Wheels Mounted
- **** = With Wheels Removed

	Before First Vehicle Use (may be performed by vehicle manufacturer)	Daily	Every 3 Months	Every 12 Months	When System Components Are Replaced	ModuLT Service Manual L30048 Page Reference
Braking Force Distribution	C/I*			C*	C/I*	7
Brake Adjustment Function				C**		12
Safety Check (in accordance with Industry recommended practices)		C*		C**		17
Brake Pads			I*	I**		18
Brake Disc			I*	I**		20
Plugs and Protective Cups				I**		21
Thrust Plate Guide Pins				I**		22
Actuator Interface				I**		23
Slide Pin Bellow Seals				I**		26
Adjustment Screw Bellow Seals				I**		27
Slide Function				I**		29

For questions regarding maintenance of the ModuLT Air Disc Brake, please refer to the Service Manual (L30048) or contact a Haldex Technical Service Representative at 1-800-643-2374.

Innovative Vehicle Solutions

Haldex Brake Products Corporation
 10930 North Pomona Avenue
 Kansas City, MO 64153-1256
 Phone: 816-891-2470
 Fax: 816-891-9447

Haldex Limited/Haldex Limitée
 500 Pinebush Road, Unit 1
 Cambridge, Ontario N1T 0A5 CANADA
 Phone: 519-621-6722
 Fax: 519-621-3924

www.haldex.com